Standard Operating Procedures Truck Detailing

Paint Finishing: Small Areas **Product List** 3M™ Trizact™ Hookit™ Clear **Initial Defect Removal** Coat Sanding Disc, 75mm, P1500, PN 05601 DA sand the repair area with a 75mm P1500 finishing film disc, removing all paint defects. Wipe panel clean. When using 3M™ Trizact™ 3M™ Hookit™ Finishing Abrasives, use a light mist of water while Film Disc, 75mm, sanding to avoid clogging of the disc. P1500, PN 51267 3M™ Hookit™ Soft Interface Pad, 75mm, PN 05771 Scratch Refinement P3000 Refine the P1500 scratches with a DA and a 75mm 3M™ Pistol Grip Disc P3000 3M[™] Trizact[™] Foam Disc used damp with Sander, PN 33577 a soft interface pad. Wipe panel clean. 3M™ Trizact™ Hookit™ Foam Disc, 75mm, Scratch Refinement 6000 (Optional) 3000, PN 50415: 6000, PN 51131 Refine the P3000 scratches with a DA and a 75mm 6000 3M™ Trizact™ Foam Disc used damp with a soft interface pad. To thoroughly remove 3M™ Perfect-It™ III Fast Cut previous scratches go over each area five times. Plus Extreme Compound, The use of P3000 is required prior to 5000 for 865mL, PN 51815: best results. 432mL, PN 51816 3M™ Perfect-It™ III Compounding Pad, 75mm, PN 50499 Compound the repair area with a 75mm polisher. Use a 75mm foam compound pad and the appropriate rubbing compound. 3M™ Perfect-It™ III Wipe panel clean. Extra Fine Plus Compound, PN 80349 3M™ Perfect-It™ III Polishing Pad, **Polish** 75mm, PN 50536 Polish the repair area with a 75mm polisher. Use a 75mm black foam polishing pad and the appropriate machine polish. Wipe panel clean 3M™ Perfect-It™ III with a yellow microfiber cloth. Ultrafina SE Polish. PN 50383 3M™ Perfect-It™ III **Swirl Elimination** Polishing Pad. Ultrafine polish the repair area with a 75mm 75mm, PN 50457 polisher. Use a 75mm blue foam polishing pad and ultrafine machine polish. Leave a light film of polish on the surface and wipe the panel clean with a blue microfiber cloth. 3M™ Disposable Ear Plugs, PN 1100 3M™ Maintenance Free Final Detail Half Mask Respirator, PNs 6962/6963 or 7502/7503 Clean sling from adjacent panels and door

apertures areas. Doing this immediately after the

repair will greatly improve the ease of this step.





















Think About Your Health





3M™ SecureFit™ 200 Series Protective Eyewear, clear, PN SF201AF

Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment